

# Interiors

## Boats to be repainted

wood in view



### Preparation:

Scrape the areas that are scaling and sand with P 240 or grey Scotch Brite; remove all dust and clean.

Nr. coats	Product Code	Interval between coats		Thickness of layer in $\mu\text{m}$ per coat		Theor. coverage mq/L per coat	Thinner (%)	Application remarks
		min. (hrs)	max. (hrs)	wet	dry			
2-4	ALTURA UV MAT 648.000	18	...	95	25	18	703 (10-15)	Sand between coats with P400.

## New or restored boats

wood in view



### Preparation:

The wood must be perfectly dry and free from all traces of dirt, grease, dust or old paint. Sand with P 100.

Nr. coats	Product Code	Interval between coats		Thickness of layer in $\mu\text{m}$ per coat		Theor. coverage mq/L per coat	Thinner (%)	Application remarks
		min. (hrs)	max. (hrs)	wet	dry			
1	BIOWOOD 647. ...	12	...	60	10	15	703 (15)	
3-5	ALTURA UV MAT 648.000	18	...	95	25	18	703 (10-15)	Sand between coats with P400.